

HAND RAILS & WIND SCREEN

	<p>Hollow Base Shoe Drilled w/ Counter-bore</p> <p>Glass: 1/2" Mono 2-1/2" x 4-1/8"</p> <p>Item # BAD212 (BA1)</p>		<p>End Cap for: Hollow Standard 1/2" Shoe 2-1/2" x 4-1/8" CL/BK/BS/PS Item # EC12C (BA8) EC12B (BA9) EC12BS (BA10) EC12PS (BA11)</p>
	<p>Hollow Base Shoe Drilled w/ Counter-bore</p> <p>(for 9/16" LAMI glass) 2-7/8" x 4-3/4"</p> <p>Item # BAD278 (BA2)</p>		<p>End Cap for: Hollow 9/16" Lami Shoe (for 9/16" LAMI glass) 2-7/8" x 4-3/4"</p> <p>Item # EC278C (BA12) EC278B (BA13) EC278BS (BA14) EC278PS (BA15)</p>
	<p>Low Profile Base Shoe Drilled w/ Counter-bore</p> <p>(for 1/2" glass) 2 1/4" x 3 1/2"</p> <p>Item # BAD214 (BA3)</p>		<p>End Cap for: Low Profile Solid Shoe 2 1/4" x 3 1/2" CL/BK/BS/PS Item # EC214C (BA17) EC214B (BA18) EC214BS (BA19) EC214PS (BA20)</p>
	<p>Wide Screen Shoe Drilled w/ Counter-bore</p> <p>(for 1/2" glass) 1 3/8" x 2 3/4"</p> <p>Item # BAD138 (BA4)</p>		<p>End Cap for: Small Profile Solid Shoe 1 3/8" x 2 3/4" CL/BK/BS/PS Item # EC138C (BA21) EC138B (BA22) EC138BS (BA23) EC138PS (BA24)</p>
	<p>Hollow Base Shoe 1/2" (Fascia) Prep</p> <p>Glass: 1/2" Mono 2-1/2" x 4-1/8"</p> <p>Item # BAF212 (BA5)</p>		<p>Aluminum Drain Block 2 x 2 1/2" x 3/8"</p> <p>Item # ADB2212 (BA25)</p>
	<p>Hollow Base Shoe 9/16" Lami (Fascia)</p> <p>Glass: 9/16" Lami 2-7/8" x 4-3/4"</p> <p>Item # BAF916 (BA6)</p>		<p>KWIXSET - Cement (Exterior Use)</p> <p>25 gal / 50 gal</p> <p>Item # KWIX25 (BA26) KWIX50 (BA27)</p>
	<p>Cladding for Base Shoe</p> <p>RFQ, Please Specify: -Dimension x Length -Finish -Qty of Left/Right</p> <p>Estimate/Lead time provided within 24hrs</p> <p>Item # BACLD (BA7)</p>		<p>ROCKITE - Cement (Interior Use)</p> <p>10 gal / 50 gal</p> <p>Item # ROCK10 (BA28) ROCK50 (BA29)</p>
		<p>Concrete Wedge Anchor Wood Deck Hex Lag Screw Concrete Screw</p> <p>* Please see Page 18</p>	