



## Wind Load Charts

#### $1\frac{3}{4}$ " x 4" x $\frac{1}{4}$ " CENTER GLAZED SYSTEM









With 12 GA. Steel Stiffener

### **Curve Representation**


A = 15 PSF


B = 20 PSF


C = 25 PSF


## Wind Load Charts

#### $1\frac{3}{4}$ " x 4" x $\frac{1}{4}$ " CENTER GLAZED SYSTEM









With 12 GA. Steel Stiffener

#### **Curve Representation**


A = 15 PSF


B = 20 PSF


C = 25 PSF

# Wind Load Charts

 $1\frac{3}{4}$ " x 4" x  $\frac{1}{4}$ " CENTER GLAZED SYSTEM










A = 15 PSF

B = 20 PSF


C = 25 PSF






Wind Load Charts

 $1\frac{3}{4}$ " x 4" x  $\frac{1}{4}$ " CENTER GLAZED SYSTEM









A = 15 PSF


B = 20 PSF


C = 25 PSF





1  $\frac{3}{4}$ " x 4" x  $\frac{1}{4}$ " CENTER GLAZED SYSTEM





### **Curve Representation**

A = 15 PSF

B = 20 PSF

C = 25 PSF